Lever version Panama UER81 by KARCHER DESIGN

Lever sets for standard duty for residential interior use and light duty for commercial interior use.

Standard Features:

- 3 piece solid fixing rose $\emptyset 2^{5}/_{8}$ (67mm) which will allow concealed fixing
- Spring loaded levers minimize droop and provide smooth, fast return action of levers heavy duty bolt through fixing prevents lock chassis rotations
- diameter of handle: 1 3/8%(34mm)
- Door range: 1 ¼%(31mm) . 2%(51mm) standard
- Backset: 2³/₈ (60 mm) backset latch standard.
- Stainless steel T-strike plate with plastic dust cover
- Stainless steel latch face plate

Options:

PAS - passage latch, backset 2 3/8+(60mm) and T-strike plate PRI . privacy latch backset 2 3/8+(60mm) and T-strike DUM . Full Dummy DUML . Half Dummy Left DUMR- Half Dummy Right

Special options (to be ordered separately)


UZA2570 PAS . Passage Latch with backet 2 3/4+(70mm) UZA3070 PRI . Privacy Latch with backet 2 3/4+(70mm) UZA2500 LS . Full Lip strike UZUL P67 . UL-Latch

Finish: satin stainless steel (finish code 71)


Karcher article no.: ER81 PAS 71 . with passage latch, backset 2 3/8+(60mm) and T-strike plate ER81 PRI 71 . with privacy latch, backset 2 3/8+(60mm) and T-strike plate ER81 DUM 71 . full dummy ER81 DUML 71 . half dummy left ER81 DUMR 71 . half dummy right

ER81B PAS 71 . Braille with passage latch, backset 2 3/8+(60mm) and T-strike plate ER81B PRI 71 . Braille with privacy latch, backset 2 3/8+(60mm) and T-strike plate ER81B DUM 71 . Braille full dummy ER81B DUML 71 . Braille half dummy left ER81B DUMR 71 . Braille half dummy right


Dimensional detail: Rose



Handle



Models Privacy and Passage



1

MARK DOOR AND DRILL HOLES

• Draw a level 3" (76mm) centerline on both sides of the door. The standard height for a handle set is 36" (914mm) from finished floor.

(2pc.)

(1pc.)

(2pc.)

(2pc.)

(2pc.)

(1pc.)

(1pc.)

(1pc.)

(1pc.)

(1pc.)

(4pc.)

(1pc.)


(1pc.)

(1pc.)

(4pc.)

(1pc.)

• Fold template over edge of door, mark site 2 3/8" (60mm) or 2 3/4" (70mm) to determine the centerpoint of holes.




- Please pay attention to the diffrent door thickness and thus different center line.
- Drill a 2 1/8" (54mm) hole half way through the door on each side to prevent splintering of door. Where the door is marked for the center of the latch, drill a 1" (26mm) hole.
- Cut out a 2 9/32" x 1" x 1/8" (58x26x3mm) base.
- Latch dosen't take the bevel of the door into account.
- · Bore from the lower end of the bevel to allow for this.

Models Privacy and Passage

2.1

INSTALL LATCH FOR PRIVACY

- Install latch (7a) and face plate (8) using wood screws provided (9).
- Make sure the threads to receive the privacy push pin (2) on the latch are facing the side you want to lock.
- The throw of the latch can be rotated 180 degrees to accommodate the desired swing of the door.



2.2

INSTALL LATCH FOR PASSAGE


- Install latch (7b) and face plate (8) using wood screws provided (9).
- The throw of the latch can be rotated 180 degrees to accommodate the desired swing of the door.



INSERT THE SPINDLE (6a or 6b)

Important:

- \bullet Insert the spindle (6a or 6b) through the latch in the way that the point of the grub screw
- (13) can break through the thinnest side.
- The split spindle for privacy sets (6a) is to be inserted until engaged.
- For passage sets the standard spindle (6b) is to be inserted in the center of the latch.



Female thread

1b


14

Δ



INSTALL LEVER SETS FOR PRIVACY / PASSAGE

• Push one side of the handle set over the spindle (6a or 6b) until the rose is flush with the door.




Models Privacy and Passage

- Push the other side of the handle set over the spindle.
 Align the fixing lugs of the rose base plate (4) with the fixing holes on the rose.
 Fixing lugs
 Fixing hole
 1a
 Hole (Privacy only)
 - Place screw overring (5) over the handle and tighten by hand.
 - Install grub screws (13) with supplied allen key (12) on both sides of handle until penetrated through spindle wall.
 - Only for Privacy: Screw in the privacy push pin (2)

INSTALL STRIKE

5

- Mark the position of the latch throw at the door frame for the strike plate location.
- Using the strike plate (10) as a template outline the position in pencil.
- Prior to installing the strike plate chisel a 1 ½" (38.1mm) high, ⁷/₈" (22.225mm) wide and ⁵/₈" (15.875mm) deep hole into the door frame for the plastic dust cover (11). Chisel door frame to fit strike plate (10) flush approximately ¹/₈" (3.175mm) in depth..
- Install dust cover (11) and strike plate (10) using supplied wood screws (9)



2

5

13 12 (Privacy only)

Models Privacy and Passage

LIMITED WARRANTY

KARCHER GMBH ("KARCHER") WARRANTS TO THE ORIGINAL RETAIL PURCHASER ("PURCHASER"), BUT TO NO OTHER PERSON, THAT KARCHER'S PRODUCTS ("PRODUCTS") SHALL BE FREE FROM DEFECTS IN MATERIAL OR WORKMANSHIP FOR A PERIOD OF ONE (1) YEAR FOLLOWING THE PURCHASE OF THE PRODUCTS FROM AN AUTHORIZED DEALER. KARCHER 'S SOLE OBLIGATION UNDER THIS LIMITED WARRANTY SHALL BE, AT THE POTION OF KARCHER, TO REPAIR OR REPLACE PRODUCTS WHICH KARCHER DETERMINES, IN IST SOLE DISCRETION, TO BE DEFECTIVE AND WHICH ARE RETURNED TO KARCHER BY AN AUTHORIZED DEALER WITHIN ONE (1) YEAR FROM THE DATE OF PURCHASE OF THE PRODUCTS.

Please refer to this Product's packaging for a full description of Karcher's limited warranty policies.

